



Operation Manual
For
Sodir
Vitro Ceramic Machines
Models – Panini VC, Majestic VC, PVC-400



PANINI VC



MAJESTIC VC



PVC 400

765 Westminster Street • Providence, Rhode Island 02903 • U.S.A.
Tel: (401) 273-3300 Fax: (401) 273-3328
www.equipex.com e-mail: service@equipex.com





IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all the instructions before use.
2. Do not touch hot surfaces; use handles or knobs.
3. To avoid electric shock, **do not immerse the power cord, or any part of the unit**, in any liquid.
4. Close supervision is necessary when any appliance is used, especially around children.
5. Unplug appliance from the electrical outlet when not in use, and before cleaning. Allow appliance to cool before installing or removing any parts or accessories, and before cleaning.
6. Do not operate any appliance with a damaged cord or plug, or if appliance should sustain damage, or malfunction in any way. In this event, return appliance to the nearest authorized service facility for examination, repair or adjustment.
7. The use of accessories and/or attachments not recommended by the appliance manufacturer may cause injury or damage to the appliance, and may void your warranty.
8. Do not use outdoors.
9. Do not allow the power cord to hang over the edge of a table or counter, or to be exposed to hot surfaces, as damage may occur.
10. Do not place appliance on or near a burner, or in a heated oven.
11. To disconnect an appliance, **first** turn all controls to the 'off' position; *then* unplug the power cord from the wall outlet.
12. Do not use appliance other than for its intended use.
13. SAVE THESE INSTRUCTIONS FOR LATER USE!

INTRODUCTION

The **SODIR** VITROCERAMIC GRILLS — Models PANINI VC, MAJESTIC VC and PVC - 400 — are uniquely designed to offer fast, quality cooking. They are ideal for last minute preparation, as they ensure very quick cooking of sandwiches and such foods as steak, hamburgers, and sausages. This is due to the design of the ceramic chamber under the glass. Cooking is achieved by both direct heat transfer from the Vitroc ceramic plate to the food, cooking the outside, and by infrared rays that cook the center of the product, thus preserving its nutritional value. The grills are versatile in application and easy to operate. The moveable top on models Panini and Majestic is spring counterbalanced. Top and bottom heating elements are thermostatically controlled up to 570° F. The units come equipped with a removable front drip tray.

Specifications:

Model	Electrical	NEMA Plug
PANINI VC	120V, 1.8KW, 14 Amps	5-15 P
MAJESTIC VC	208/240V, 1PH, 3.3KW, 12/14 Amps	6-20 P
PVC-400	120V, 1PH, 1.8KW, 14 Amps	5-15 P

Preheating

Turn the grill ON using the ON/OFF switch(s) (the green light(s) will go on) and turn the temperature control knob(s) to the desired temperature. The orange light(s) will go ON, and stay ON, until the desired temperature is reached. The orange light(s) will then go out. The preheat time will vary depending on the cooking temperature settings and the electrical specifications of your model. It will normally take 5-10 minutes for your grill to reach cooking temperature. After reaching the set temperature, the orange light(s) will cycle ON and OFF as the thermostat cycles to maintain temperature. The green light(s) remain ON until the unit is shut off with the power switch.

Cooking

SODIR Panini grills can be used for a wide variety of foods. Following are some suggested guidelines for foods frequently cooked on this grill. Cooking times will vary depending on the food products, temperature settings and desired results.


<u>Sandwich</u>	Temperature:	400-450° F
	Time:	1-3 minutes
<u>Wrap</u>	Temperature:	375-450° F
	Time:	30-90 seconds
<u>Chicken Breast Filet</u>	Temperature:	475-500° F
	Time:	2-3 minutes
<u>Beef Steak</u>	Temperature:	475-550° F
	Time:	2.5-4.5 minutes
<u>Burger</u>	Temperature:	500-550° F
	Time:	2-4 minutes

Adjusting Handle Tension

WARNING: Disconnect (unplug) electrical power supply before servicing

Allow the grill to cool. Remove the spring protection cover, at the top rear of the unit, by unscrewing the two Torx screws, and then pulling it up. With a flat head screwdriver, tighten or loosen the screws on the handle straps until the desired tension is achieved. There are four (4) screws, two (2) on each side. Re-install the spring protection cover and Torx screws prior to use. *See attached drawing below.*

**PANINI GRILL REAR
TOP VIEW**



**PANINI GRILL
REAR VIEW**

CLEANING

WARNING: Disconnect (unplug) electrical power supply before cleaning

Allow the grill to cool before cleaning. Carefully scrape the debris from the upper (if supplied) and then lower grill plates, and then clean with glass top stove cleaner. Never allow cold water, or any cold material, to contact the warm grill surface as it may crack. To clean the grill, scrape or brush the debris toward yourself and through the hole provided, into the removable drip tray. Use a cloth dampened slightly with a soap and water mixture to clean the stainless steel housing, upper grill covers, spring protection cover and the drip tray. Clean the grill thoroughly at the end of each day. Failure to do so may cause hard to remove build up. In order to remove this build up from the grill plates, you may carefully use a commonly available grill scraper knife.

DO NOT spray the unit with any cleaning liquid before unplugging it

DO NOT allow water to drip into the housing or around the electrical components


DO NOT immerse in water for cleaning


DO NOT allow cold water to contact warm surface

You should inspect all parts on a regular basis to ensure that all is in proper working order. If a part is damaged, have the unit repaired by an authorized service agency prior to returning the unit to operation. If you have trouble locating a service agency in your area, please consult our website at <http://www.equipex.com/>, or call us at 1-800-649-7885 and ask for customer service.

These models must be taken to a service facility; in-store service is not covered.


Face Plate – Panini, PVC-400





PVC-400, Panini, 120V

1	Lighted Switch
2	Thermostat
3	Top Heating Element
4	Bottom Heating Element
6	Orange Pilot Light
7	Two Hole Terminal Block
8	Three Hole Terminal Block
9	High Limit Thermostat




Majestic VC 220V

1	Switch
2	Thermostat
3	Top Heating Element
4	Bottom Heating Element
5	Green Pilot Light
6	Orange Pilot Light
7	Two Hole Terminal Block
8	Three Hole Terminal Block
9	High Limit Thermostat


Spare parts **PS-400 VC 110 V**

DWG #	Part Number	Qty	Spare part
1	53100	1	Hole cover
2	A16013	1	Three holes domino
3	A16012	1	Two holes domino
4	A07033	1	Pushing switch
5	A08003-1	1	Orange pilot light
6	A06042	1	Thermostat
7	A14078	1	Knob
8	A13003	4	Foot
9	B07001	2	Compression spring
10	37234	1	Ceramic chamber lock
11	37242	1	Bottom casing
12	D06003	1	Ceramic chamber
13	37230SE	1	Drip tray
14	A10032	1	Cord closer 16
15	C01008	1	Cord with plug
16	A06050	1	Safety thermostat
17	53101COL2	1	Casing with flat glass




Spare parts **PANINI VC 110 V**

DWG #	Part Number	Qty	Spare part
1	D06001	2	Ceramic chamber
2	F01064	1	Handle assembly
3	A15008	1	Top plate handle
4	37240	1	Stainless steel cover
5	B04027	2	Handle strap
6	A16013	1	Three holes domino
7	A16012	1	Two holes domino
8	A07033	1	Pushing switch
9	A08003-1	1	Orange pilot light
10	A06042	1	Thermostat
11	A14078	1	Knob
12	A13003	4	Foot
13	B07001	4	Compression spring
14	37234	2	Ceramic chamber lock
15	37242	1	Bottom casing
16	37230SE	1	Drip tray
17	A10032	1	Cord closer 16
18	C01008	1	Cord with plug
19	C04008	1	Spring girdle
20	37237	1	Spring protection
21	A06050		Safety thermostat
22	37239COL	1	Top frame with grooved glass
22	37239COL2	1	Top frame with flat glass
23	37241COL2	1	Casing with flat glass



Spare Parts MAJESTIC VC 220

DWG#	Part Number	Qty	Spare part
1	D06002	4	Ceramic chamber
2	F01063	2	Handle assembly
3	A15008	2	Top plate handle
4	37251	2	Stainless steel cover
5	B04027	4	Handle strap
6	A16013	1	Three holes domino
7	A16012	2	Two holes domino
8	A07033	2	Pushing switch
9	A08003	2	Orange pilot light
10	A06042	2	Thermostat
11	A14078	2	Knob
12	A13003	4	Foot
13	B07001	8	Compression spring
14	37247	4	Ceramic chamber lock
15	37253	1	Bottom casing
16	37244SE	1	Drip tray
17	A10032	1	Cord connector
18	C01008	1	Cord with plug
19	C04008	2	Spring gridle
20	37248	2	Spring protection
21	A06050	2	Safety thermostat
22	37250COL	2	Top frame with grooved glass
22	37250COL2	2	Top frame with flat glass
23	37252COL2	1	Casing with flat glass





LIMITED WARRANTY

Your new **EQUIPEX** product is warranted to the original purchaser for a period of one year from the date of purchase.

This limited warranty is against defects from original factory imperfections in material and/or workmanship and includes labor for replacement of defective parts, provided repairs are performed by an authorized service agency. Our obligation under this warranty is limited to repairing or replacing any part or parts thereof. The CUSTOMER must inform the Service Agency of warranty coverage and provide a copy of the dated sales or delivery receipt BEFORE WARRANTY REPAIRS BEGIN. Replacement parts and accessories are warranted for ninety (90) days from the date of purchase when purchased separately and will be verified by dated sales receipt or packing slip for that item. All parts or accessories replaced under warranty must be returned to the Service Agency.

This warranty applies only to equipment under normal use and service in the U.S.A. and Canada. It does not apply to any item which has been repaired or altered in any way so as, in the judgment of EQUIPEX, to affect its reliability.

THE FOLLOWING ARE NOT COVERED UNDER WARRANTY:

1. Damage caused by abuse, misuse or dropping or other similar incidental damage caused by, or as a result of, customer failure to follow assembly, operation, cleaning, user maintenance or storage instructions.
2. Labor to replace inoperative parts such as bulbs, plugs or racks due to normal wear and tear or abuse.
3. Materials or labor to repair scratched, stained, chipped, pitted, dented or discolored surfaces, attachments or accessories.
4. Transportation charges to or from a service agency for repair of your machine. If you should have questions relating to this issue, please call **Equipex** at 1-800-649-7885.
5. Labor charges to install or test attachments or accessories, which are replaced for any reason.
6. SHIPPING DAMAGES. Visible and hidden damages are the responsibility of the freight carrier. The consignee must file the claim promptly against the carrier. KEEP ALL ORIGINAL CONTAINERS AND PACKAGING MATERIAL FOR CARRIER INSPECTION.
7. Products placed or stored in the equipment are not subject to this warranty and no responsibility is assumed thereof.

THIS WARRANTY IS GIVEN EXPRESSLY AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, FOR MERCHANTABILITY AND FOR FITNESS TOWARD A PARTICULAR PURPOSE AND CONSTITUTES THE ONLY WARRANTY MADE BY EQUIPEX, LLC. IT NEITHER ASSUMES, NOR AUTHORIZES ANY PERSON TO ASSUME FOR US, ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF THE SUBJECT EQUIPMENT.

For service, please call **EQUIPEX** at 1-800-649-7885, menu option # 3

765 Westminster Street • Providence, Rhode Island 02903 • U.S.A.

Tel: (401) 273-3300

Fax: (401) 273-3328

www.equipex.com

e-mail: service@equipex.com